

WIRE TERMINAL TOOL

Terminal Blocks With Round Connectors:

Select the sleeve of the tool which will slip into the hole of the connector block. While holding the wire of the terminal you are removing with one hand, insert the tool into the block and rotate slightly until it bottoms out in the connector block. Leave the tool in place and pull the wire holding the terminal block.

Spade Type Terminal Blocks:

On blocks with single retaining barbs use the large U-fork. Insert one blade of the fork in the slot behind the barb, letting the other blade slip down the outside of the terminal block while holding the wire with other hand. When tool is pressed in as far as it will go, grasp terminal block and pull wire out of it.

On spade type terminals with two retaining barbs use small U-fork. Insert tool so that each blade goes in a slot behind a barb.