



Mounting Suggestions

Harley-Davidson® Softail Standard Tire

Fits only: 2007-2010 FLSTC Heritage, 2005-2010 FLSTN Deluxe,
2000-2005 FLSTSC Springer

Cyclone Solo Seat and Frame Mounting Plate

Installation Hardware Included:

- | | |
|--|---|
| (1) #B30126 steel nose bracket | (2) 5/8" thick rubber bumpers |
| (1) 3/4" thick plastic spacer | (2) 1/4-20 x 3/4" long Phillips truss head screws |
| (1) 1/4-20 x 1 - 1/2" long hex head bolt | (2) 1/4-20 x 1-1/2" long Phillips truss head screws |
| (1) 1/4-20 x 1/2" long Phillips truss head screw | (5) 1/4" flat washers |
| (1) 1/4-20 flange nut | (2) 1/4" chrome washers |
| (2) 1/8" thick rubber washers | (2) 1/4"-20 chrome acorn nuts |

Install Cyclone Solo Seat onto Frame Mounting Plate

1. Decide on position of Cyclone Solo as follows:

- Forward position, use rear threaded insert in seat nose.
- Back position, use front threaded insert in seat nose. This will also require two 5/6" diameter holes to be drilled at marked locations on frame mounting plate.

2. Attach nose bracket #B30126 to frame mounting plate using 1/4-20 x 1/2" long truss head screw and 1/4-20 flange nut. Screw goes through from top of frame mounting plate, through nose bracket, and is secured with flange nut. Tighten.

3. Insert 1/4-20 x 1 1/2" long hex head bolt with washer through bottom of nose bracket, through frame mounting plate, through 3/4" thick plastic spacer, and into either the front or rear threaded insert in the nose of the seat as was decided in step 1. Do not tighten.

4. For the forward most seating position: Insert 1/4-20 x 3/4" long Phillips truss head screws with washers through bottom of frame mounting plate, through 1/8" thick rubber washers, and into threaded inserts in rear section of the Cyclone solo seat.

For the rearmost seating position: Insert 1/4-20 x 1 1/2" long Phillips truss head screws with washers through bottom of frame mounting plate, through the 5/8" thick rubber bumpers, and into the threaded inserts in rear section of the Cyclone solo seat.

5. Tighten nose bolt and rear screws to secure solo seat to frame mounting plate.



Install Frame Mounting Plate onto bike frame

1. Slide nose bracket on bottom of frame mounting plate into receiver on bike frame.
2. Align the two holes at the rear of the frame mounting plate with the two studs in the rear fender and attach to bike using the two chrome washers and two chrome acorn nuts. Tighten.



Enjoy your new Mustang seat



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 860-582-9633, Monday through Friday 9:00 - 5:30 Eastern or send an email to questions@mustangseats.com or visit our website at www.mustangseats.com

For care and maintenance of our seats, please go to our website under [“Support”](#).

Ref: Cyclone Solo Seat part #'s 76615, 76616, 76617, 76618, 76621
Frame mounting plate: 76631