

# SPORTSTER HIGH PERFORMANCE A/C ASSEMBLY



## REQUIRES:

1/4" 12 Point Wrench  
1/2" 12 Point Wrench  
3/16" Allen Wrench

**IMPORTANT:** A/C assembly will not run properly without remapping the E.F.I. system or rejetting the carburetor.

**NOTE:** Use BLUE LOCTITE on all hardware

## INSTALLATION

1. Completely remove stock air cleaner assembly.
2. Installed the a/c back plate & vent plates with the breather bolts.  
Do not fully tighten the breather bolts
3. Install the (3) 1/4-20 Allen screws using blue Loctite to the throttle body with the stock a/c gasket.
4. Tighten the breather bolts
5. Install the outer cover, K&N filter, and stand-off with the 1/4-20 12 point bolt using blue Loctite.

