



# Mounting Suggestions

## Harley-Davidson® Road King 1994-1996

### Solo Seat

#### Hardware:

- White Flat Nylon Washer x 2 (Included)



#### **Baseplate Features:**

The solo features a 16 gauge formed steel baseplate with rubber bumpers to minimize vibration and prevent it from touching the frame. It is a direct replacement for the stock solo. Two chrome mounting tabs that align with the fender inserts/studs.

#### **Stock Two-Piece Seat Removal Steps**

1. Remove the rear fender screw.
2. Slide the passenger seat back and up.
3. Remove solo mounting bolts located at the back of the solo.
4. Slide the solo seat back and up to remove.

#### **Stock Solo Seat Removal Steps**

1. Remove solo mounting nuts.
2. Slide the solo back and up to remove.

#### **Stock One-Piece Seat Removal Steps**

1. Remove the rear fender screw.
2. Remove hand strap that is secured to the motorcycle on each side of the seat where the front saddle bag mount is located.
3. Slide the stock seat back and up.

## **Mounting of Mustang Seat**

1. Engage nose of seat, pushing seat as far forward as possible so that the mounting holes/studs in the fender are in the middle to back edge of the slotted tabs.
2. A firm downward chop to the nose of the seat will push the seat closer to the chrome dash.
3. Seat is spring loaded for a tight fit so the mounting tabs will be approximately 1" - 1 1/2" above the fender.
4. The supplied nylon washers go between the mounting tabs and the fender.
5. Start one mounting bolt/nut to finger tight, do second then secure both.

**Enjoy the Comfort of your new Mustang Seat!**



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to [questions@mustangseats.com](mailto:questions@mustangseats.com) or visit our website at [www.mustangseats.com](http://www.mustangseats.com).

For care and maintenance of our seats, please go to our website under "[Support](#)".

Ref: part #'s 75566, 79101