



INSTALLATION INSTRUCTIONS
SIDE STRAPS for 2011-2013 FXS Blackline®,
2012-2014 FLS Softail Slim® with
8.75" KHROME WERKS® Sissy Bars
Mfg. p/n 263860
(See pkg. label for Dist. p/n)

ATTENTION INSTALLER (if other than owner):

Please forward this instruction sheet and the warranty card to the purchaser of this product. These instructions also contain valuable information necessary to the end user.

INTRODUCTION:

These instructions describe the procedure for properly installing KHROME WERKS® Sissy Bar side straps and uprights onto Harley-Davidson® 2011-2013 Blackline® and 2012-2014 Softail Slim® models. Review instructions carefully before beginning, as they contain important information. Please retain for future reference.

Particularly important information is distinguished in these instructions by the following notations:

NOTE: A NOTE provides key information to make procedures easier or clearer.

CAUTION: A CAUTION indicates special procedures that must be followed to avoid damage to the motorcycle or accessories.

WARNING: A WARNING indicates special procedures that must be followed to avoid injury or death to a motorcycle operator or person inspecting or repairing the motorcycle.

TOOLS REQUIRED:

- 1 – T40 Torx wrench
- 1 – 5/16" hex key wrench
- 1 – 5/32" hex key wrench

PROCEDURE:

CAUTION: When removing rear fender reflectors, use care not to damage fender paint.

CAUTION: Buildup of chrome plating on fasteners may cause seizing or binding during installation. Use anti-seize lubricant on the 1/4" buttonhead screws to prevent this.

1. Carefully remove the rear fender reflectors if factory installed. Remove any adhesive remaining from the side of the fender. Use 3M® adhesive remover. Remove the fender strut screws. Do one side at a time. Discard screws.

2. Position the side strap against the fender support. Line up the mounting holes in the side strap with the holes in the fender strut.

3. Apply 1-2 drops of Loctite® 242 (blue) to threads of provided 3/8"-16 buttonhead screws. Install screws through side strap, fender strut, fender and into the nut supports inside the fender.

4. Repeat for other side.

WARNING: Federal Motor Vehicle Safety Standard (FMVSS) 108 requires all motorcycles to be equipped with side reflectors. Loss of visibility to other motorists could result in an accident. Relocate the side reflector to an unobstructed area of the fender or use a DOT/SAE-approved accessory reflector, and affix to the side strap.

5. Install sissy bar upright (purchased separately – use only 8.75" side uprights) into side straps, using 1/4"-20 buttonhead screws with anti-seize applied to threads. Tighten screws to 8-10 ft-lbs (dry).

WARNING: Before operating motorcycle, check all hardware to be sure it is tight.

USE AND CARE: Wash your accessories with the same care you use when washing your motorcycle. Use mild soap and water. DO NOT use abrasive chemicals or cleaners, or high pressure washers.

chrome	black	
263604	263800	8.75" Lowboy Upright
263601	264801	8.75" Mini Lowboy Upright
263611	263811	8.75" Round Upright
264190		8.75" Bantam Upright

KHROME WERKS®

div. D.S. Manufacturing, Inc. • 67 Fifth St. N.E. • Pine Island, MN 55963