



www.jokermachine.com, sales@jokermachine.com
(P) 909-596-9690, (F) 909-596-9693

Fork Mount Turn Signals Installation

1. Lift bike on a bike stand until the front wheel is off the ground. Once that is done you can lower the fork tubes enough to install the lights.
2. Loosen upper and lower triple clamp pinch bolts on fork legs. Slide fork tube down far enough to slide lights onto fork tubes. Raise fork tubes back up and torque to factory spec. 30' - 35' lbs.
3. Place lights in desired location and tighten mounting bolts using BLUE LOCTITE or any medium strength thread locker.
4. For cleanest installation figure out how much heat shrink is need and slide over wires before soldering or connecting.

NOTE: READ BEFORE WIRING

This assembly comes with single function L.E.D. lights. Depending on the year of the bike and what functions you want the lights to have, you might have to use a load equalizer or dual function converter module (typically called Intensifiers).

Please call Joker Machine if needed.

5. Wire bike as necessary.
Red wire is POWER (+), Black wire is GROUND (-)