



Mounting Suggestions

Harley-Davidson® FLHT and FLTR 1997-2007

Cyclone Solo Seat and Frame Mounting Plate

Installation Hardware Included:

- | | |
|---|--|
| (1) #B30125 steel nose bracket | (2) 1/4-20 x 1/2" long screws |
| (2) 5/8" thick rubber bumpers | (2) 1/4-20 x 1-1/2" long screws with washers |
| (1) 1/4-20 x 3/4" long screw and washer | (2) 1/4-20 chrome acorn nuts with chrome washers |

Install Cyclone Solo Seat onto Frame Mounting Plate

1. Attach nose bracket #B30125 to bottom of Cyclone solo seat using the two 1/4-20 x 1/2" long screws.
2. The 1/4-20 x 3/4" long screw with flat washer must be inserted through the frame mounting plate from the bottom, and then into the threaded hole in the nose bracket.
3. The two 1/4-20 x 1 1/2" long screws and washers must be inserted through the frame mounting plate from the bottom, then through the two 5/8" thick rubber bumpers, and finally into the two threaded inserts toward the rear of the solo seat.
4. Tighten all three screws.



Install Frame Mounting Plate onto bike frame

1. Slide nose tab on bottom of frame mounting plate into the hole in the bike frame just behind the gas tank.
2. Align the two rear mounting holes with the two 1/4-20 threaded studs in the front of the rear fender.
3. Attach frame mounting plate to bike using the two 1/4-20 chrome acorn nuts with chrome washers.

These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 860-582-9633, Monday through Friday 9:00 - 5:30 Eastern or send an email to questions@mustangseats.com or visit our website at www.mustangseats.com

For care and maintenance of our seats, please go to our website under ["Support"](#).

Ref: Cyclone Solo Seat part #'s 76615, 76616, 76617, 76618, 76621

Frame mounting plate: 76622