



LowandMean.com
855.880.6660

STAR STRYKER
FULL WRAP FRONT FENDER
Part # LM-04S-204
INSTRUCTIONS

| | | |
|----------------------|-------------|---|
| LM-04S-204 includes: | | WARNING: Do not install with the motor warm. This is an install at your own risk. If you are not capable of installing this part successfully, then we highly suggest you take this item to a professional shop. <u>Always check the fit before sending this product off to paint.</u> |
| 1 | 243 Loctite | |

Important: You must remove the reflector bracket on the right side. You need to keep the left side bracket because that supports the brake line. If you do not use the stock brake line support bracket then you must use two washers in place of the bracket. These washers must be the same thickness as the bracket or the front fender will be offset and rub the tire.

Steps for Install:

- 1) Make sure your bike is stable, either on the kick stand or a bike stand before you begin.
- 2) Remove the current front fender that is on your Star Motorcycle.

Note: You will use your stock hardware to attach the new front fender.

- 3) Start by installing the stock bolts from the inside of the fender so that they point out.
- 4) Slide the fender in place. Apply supplied Loctite on the threads of the stock bolts.
- 5) Evenly snug each bolt until the fender sits in place.

Note: You might have to tilt the fender forward or back to fit in the desired location. Once the fender is in place and snug, evenly tighten down each bolt.

- 6) If you notice the fender is closer to the tire on one side: loosen the bolts, hold the fender out with your hand, and retighten.
- 7) Check fit and firmness after your first ride. Repeat Steps 5 - 7 if necessary.



Please contact our Tech Support if you have any issues or questions about installation

TechSupport@LowandMean.com or 855-880-6660

© 2006-2015 Low and Mean L.L.C.™, All rights reserved.