



WHEEL CHOCK INSTALLATION

PART:320377



Included in the package:

- 1 Stockton Tool Co.® Wheel Chock
- 4 8mm x 20mm threaded inserts
- 4 Button Head Screws

Tools needed:

- 25/64 drill bit
- Drill
- 8mm Allen wrench

Place the wheel chock in the desired mounting location.

With a pencil, mark the center of each key-hole as shown in the above image.(*)

Using a 25/64 drill bit, drill holes into the trailer floor.

Using a 8mm hex head allen wrench, thread the inserts into the previously drilled holes.



Align the wheel chock over the inserts, install the button head screws but do not tighten. Slide the wheel chock into the key-hole channel and tighten the the button head screws into place.