



www.namzccp.com

NAMZ Custom Cycle Products, Inc

1440 Ulmer Avenue
Oreland, PA 19075

Technical Support is available Monday-Friday, 9am-5pm EST via email at tech@namzccp.com.

Part Number: NHD-69203216



Fitment:

NHD-69203216: NAMZ fog lamp wiring harness, of Daymaker LED Fog Lamps part # 68000386 or 68000387 on 2023-2025 FLHXSE and FLTRXSE and 2024-2025 FLHX and FLTRX models.

This product is intended: When installing OEM fog lights on your 2023-Up Street or Road Glide, this harness is a must. A simple, plug-n-play "Y" harness allows for easy wiring and operation of OEM fog lamps.

What is included in this kit?

- Plug-n-play fog lamp harness

Recommended tools:

- Flashlight

WARNING!

This product should be installed by a professional motorcycle technician or reputable shop/ dealership.

Improper installation may result in chatengine damage or an electrical short.

Installation instructions:

1. Start by making sure your bike is on a flat, safe surface and the ignition is in the "off" position.
2. On the underside of the bikes engine, you will find the mating 4-position male connector for our wiring harness.
3. Once located, remove the rubber dust cap and be sure the connector is clean before connecting to our harness.
4. Make the connection.
5. Install the OEM fog lamps, part numbers 68000386 or 68000387 as shown in the factory instructions, routing the wires safely and using cable ties.
6. Be sure to route the passing lamp wires towards our wiring harness for a simple connection before securing in place under the engine using the included cable tie.
7. Now that everything is connected, turn on the bike's ignition and locate the **Settings** "gear" indicator on the Skyline info-tainment screen.
8. Scroll down to **System**, then down to **Bike Function Setup**, follow the on-screen instructions to setting up the accessory to "installed" before pressing **(CONTINUE)**.
9. Choose **Front Fog Lights** and turn this feature on.
10. Exit out of the Settings menu and scroll down to the motorcycle icon or **Bike Function** menu and search for the **Front Fog Lights** option and choose **ON**.
11. Test to be sure fog lamps are on before completing the installation!