



OG 2020+ Softail Lowrider S & ST Top Triple Tree

Please refer to your bike service manual for additional guidance.

*For a smoother installation, keep your hand controls and switches installed on the handlebar.

1. Separate the handlebar from the top triple tree.
2. Remove the OEM top triple tree.
3. At this point, consider inspecting, cleaning, greasing, and tightening your neck bearing.
4. Install your new OG Top Triple Tree on top of the fork stem and fork tubes.
5. Make sure that all pinch bolts on the triple tree are loose so it can slide freely.
6. Re-use the OEM fork stem screw and torque it to **165 in-lbs.**
7. Loosen the fork stem screw by 45°.
8. Apply the final torque to the OEM fork stem screw. **120 in-lbs.**
9. Torque all OG Top Triple Tree pinch bolts. **Refer to the attached diagram** for torque specifications and parts assembly.
10. The risers mounting blocks can be flipped for a 2" pullback setup. 1" Pullback Mounting Blocks are available and sold separately.
11. Install Risers bushing. We strongly recommend polyurethane bushings for risers lower than 9" and solid bushings for risers higher than 9".
12. Install your handlebar and risers on the top triple tree.
13. Carefully route your wires and cables using the supplied P-clamps.



OG 2020+ Softail Lowrider S & ST Top Triple Tree

OG 2020+ Softail Lowrider S & ST Top Triple Tree H-AC-82-XX

