



OG Billet Fork Stem Cap Installation-1.0

Please note that the OG Billet Fork Stem Cap will not fit with our full Triple Tree setup machined stem axle nut.

1. Before installing the OG Billet Fork Stem Cap, clean the stem nut thoroughly to ensure an easier and more secure installation.



2. Use a 5/16" Allen key to remove the set screw. Apply a small amount of blue Loctite to the threads.
3. Using a 5/32" Allen key, remove the flat-head Allen screw.
4. Apply blue Loctite to the threads.
5. Reinsert the screw and tighten it firmly until secure. **Be careful not to overtighten**; aim for snugness without forcing it excessively to avoid damage.





OG Billet Fork Stem Cap Installation-1.0

6. Slide the OG Billet Fork Stem Cap onto the OEM stem nut.



7. Thread in the set screw and tighten it firmly until secure. **Avoid overtightening** to prevent damage; aim for snug without forcing it beyond that point.

OG OG Billet Fork Stem Cap H-AC-89-XX

