





Thank you for purchasing our product. Before installing/operating the product, read the instructions carefully and retain them for future reference.

Attention!

- For installation, follow the steps described. Any damage caused by wrong installation shall be imputed to the users.
- Do not disassemble or change any parts. Opening and dissassembling this unit will void any warranty.
- Maintenance and repairs should be executed by our professionals only.

NOTE

Some procedures must be followed to avoid damages to the product.

A WARNING! Certain procedure must be followed to avoid damages to yourself, to the vehicle or to others.

1-1 ACCESSORY



1-2 Optional Accessories










5 AIR FILTER

2 INSTALLATION INSTRUCTIONS



Proceed as follows

- 1. Use appropriate tools to remove the original air filter connecting pipe and throttle valve.
- 2. Clean up the connecting hole of the air filter shell.
- 3. Install the KOSO air filter to the air filter body.
- 4. Apply silicone around the area to keep it airtight and fixed, and the installation can be completed.

