

QUICKSTART GUIDE






Scan the QR code to view the QuickStart video.








QUICKSTART GUIDE

Install the Battery













Power On









Arming Check





Flywheel Startup








Transmitter Controls

















Turning Radius





Practice




Power Off








Drive Modes



MS6X[®] Lean Adjustment



Scan the QR code and select the Manuals and Support quick links from the product page for the most up-to-date manual information.



LOSO6000 / LOSO6002