

ALLIANCE GT DROPSHIELD

DROPSHIELD™

Instead of carrying extra ProShield™ for changing light conditions, with the flip of a switch, engage the tinted DropShield™ hidden within the helmet. Tinted DropShields™ should not be used during hours of low light; instead swap out for a Yellow lens or just use the Clear ICON® ProShield™. The DropShield™ visor must only be used while the main face shield is in the fully closed position.

To order replacement lenses in a variety of colors, visit your local dealer or www.rideicon.com.

SAFETY WARNING: Your Alliance GT™ is originally supplied with a Clear ProShield™ and Tinted DropShield™. Under no circumstances should a rider use a tinted DropShield™ while a tinted ProShield™ is attached. Duplicated tinted shields will limit your vision.

DROPSHIELD™ CHANGE AND REMOVAL

REMOVAL:

1. Open the ProShield™ and lower the DropShield™
2. While firmly holding the helmet, pull the DropShield™ forward and down until two clicks are heard and the shield is free from both side clips.

INSTALLATION:

1. Begin by placing the DropShield™ Switch in the UP Position.
2. Start with the SWITCH side of the DropShield™. Align the tabs with the clips for the internal mechanism and push firmly on the lens until you hear a “CLICK” sound.
3. Repeat the process with the opposite side of the DropShield™.
4. Once installed, operate the DropShield™ Switch to ensure proper installation, and clean the DropShield™ with an ICON® lens wipe or microfiber cloth.

Some users may find it easier to change the DropShield™ with the ProShield™ and Breath Deflector removed. If the ProShield™ was removed for DropShield™ replacement, ensure the ProShield™ has been re-installed correctly before riding. The DropShield™ is not designed to be used without the ProShield™.

SAFETY WARNING: Incorrect installation of the DropShield™ may adversely affect its performance.

