

FIXED PASSENGER DRINK HOLDER ARMREST MOUNT

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.



Installation Instructions:

- 1. Park on a level surface and shut off motorcycle. Ensure the engine has time to cool before installation. Protect painted surfaces to prevent accidental damage to motorcycle.
- 2. Remove plug from armrest on side you want to install mount.
- 3. Line up slot to the top and push mount in untill it stops. Pushin screw at the front indicated in Fig. 1 and rotate mount 90 degrees clockwise to set position.
- 4. Tighten screw in front securely and mount is ready. Fig. 2
- 5. Refer to instructions provided with drink holder for installation.





Page 1 of 1



