
KAWASAKI TERYX

INSTALLATION INSTRUCTIONS:

1. Install Mount Plate Bracket as shown in Figure 3 using the holes (A) shown in Figure 2. Secure Plate using the 3/8"-16 x 1" Carriage Bolts and Nuts.

See Page 2 for continuation of instructions.




"Figure 2" Mount Plate Bracket Bolt Locations





"Figure 3" Mount Plate Bracket Install




2. Place Mount Plate up to Mount Plate Bracket and install using the 3/8"-16 x 1 1/4" Bolts and Lock Washers (B) as shown in Figures 4&6.








6. See UTV Plow Tube System instruction manual for tube attachment.



"Figure 4" Skid Plate Drill Pattern



"Figure 5" Bolt Plate Location



"Figure 6" Mount Plate Final Install






THIS MOUNT RECOMMENDS A PLOW PULLEY


SYNTHETIC ROPE PLOW FAIRLEAD PULLEY

- ALUMINUM ROLLER
- STANDARD OR WIDE



STEEL CABLE PLOW FAIRLEAD PULLEY

- RECOMMEND A PULLEY AT THE WINCH AS WELL AS PUSH TUBE VIEW EXAMPLE BELOW



12" SOFT LOOP STRAP WRAPS AROUND BUMPER OR SOLID ANCHOR POINT ABOVE PULLEY.

WHY USE A PULLEY?

MORE VERTICAL LIFTING POSITION. THIS WHEN THE WINCH FAIRLEAD AND PLOW IT CREATES A SHALLOW LIFTING ANGLE PIN POINT ARE CLOSE TO EACH OTHER WILL PROVIDE LESS STRAIN ON THE WINCH AND ENTIRE PLOW SYSTEM CHANGING THE WINCH ANGLE TO A BY ADDING A PULLEY, YOU ARE

possible POSli

STANDARD FAIRLEAD PULLEY REQUIRED FOR ALL PUSH TUBE APPLICATIONS

