



CURVED FRAME WITH LED PLATE LIGHT

- WARNING** This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.
- CAUTION** This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.
- ATTENTION** This indication alerts you to the fact that if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Included Items:



Installation Instructions:

1. Park on a level surface and shut off motorcycle. Ensure the engine has time to cool before installation. Protect surfaces to prevent accidental damage.
2. Remove two torx head screws shown in Fig. 1 and set aside. These will be reused for the new plate.
3. While supporting the plate holder and light, unplug the connector indicated in Fig. 2. Set aside OEM plate holder.
4. Place backing pad on fender as shown in Fig. 3. It should align with screw holes and have edge channels facing outward.
5. Attach base plate with led light to fender by first plugging connector to OEM connector shown in Fig. 3 and place base plate into channels shown in Fig. 3 so it is seated correctly. Replace OEM torx screws through plate and tighten. You may need to hold plastic cover box behind the fender in place while inserting screws. Fig. 4
6. Pre-flex your plate slightly, if it is metal, and place onto base plate sliding under led light to reach the correct placement. Plate should be centered on base plate. Fig. 5
7. Place protective tape along bottom of fender to protect from possible scratches. Install frame cover over top of base plate and while holding bottom of frame in install provided screw and washer at bottom of the frame, tighten securely. Fig. 6



